

Versión  
en español  
al dorso



indoor flat HDTV antenna  
multi-directional

## QUICK START GUIDE

ANT1520E Insert 02

Check out setup videos at  
[www.RCAAntennaHelp.com](http://www.RCAAntennaHelp.com)

### 1 Use the RCA Signal Finder App to find the best location for your antenna.




In the Google Play or Apple App Stores, search for “RCA Signal Finder” and look for the icon shown here. Then download and install the App.

Launch the App and follow the directions there to find the best location and orientation for your antenna.

#### Antenna Placement Tips

- ✓ The antenna works best in a vertical position, using either the integrated stand or mounted on a wall.
- ✓ Avoid metal surfaces (like a metal stand).
- ✓ Move the antenna close to or in a window.
- ✓ Position the antenna as high as possible.

### 2 Connect the antenna to your TV.



Make sure your TV is turned off. Then connect the antenna's coaxial cable to the antenna input on your TV or digital converter box.

### 3 Scan for channels on your TV.

Most TVs have a channel scan option in their menu system, many times in a SETUP or CHANNEL menu under ANTENNA.

For detailed instructions on performing a channel scan, see the owner's manual that came with your TV.

**Important:** You must perform a channel scan to receive any channels!

# STOP!

DO NOT RETURN this product to the store!  
Visit [RCAAntennaHelp.com](http://RCAAntennaHelp.com) for instructional and how-to videos.

English  
version on  
other side



antena HDTV  
para interiores /  
multidireccional

## GUÍA DE INICIO RÁPIDO

Consulte los videos de configuración en  
[www.RCAAntennaHelp.com](http://www.RCAAntennaHelp.com)

### 1 Utilice la aplicación RCA Signal Finder para determinar la mejor ubicación para su antena.




En las tiendas Google Play o Apple App, busque "RCA Signal Finder" y el icono que aquí se muestra. Ahora descargue e instale la aplicación.

Abra la aplicación y siga las instrucciones para determinar la mejor ubicación y orientación para su antena.

#### Consejos para la ubicación de la antena

- ✓ La antena funciona mejor en posición vertical, utilizando ya sea el soporte integrado o montada en una pared.
- ✓ Evite las superficies de metal (tal como un soporte de metal).
- ✓ Coloque la antena en una ventana o cerca de ella.
- ✓ Coloque la antena lo más alto posible.

### 2 Conecte la antena al TV.



Asegúrese que el TV esté apagado. Luego conecte el cable coaxial de la antena a la entrada de la antena en el televisor o caja del convertidor digital.

### 3 Busque canales en su TV.

La mayoría de televisores tienen una opción de búsqueda de canales en el menú del sistema, con frecuencia se encuentra en el menú de CONFIGURACIÓN o CANALES en la sección ANTENA.

Para obtener instrucciones detalladas sobre cómo llevar a cabo una búsqueda de canales, consulte el manual del propietario incluido con el TV.

**Importante:** ¡Debe realizar una búsqueda de canales para recibir los canales!

# ¡ALTO!

NO DEVUELVA este producto a la tienda.  
Visite [RCAAntennaHelp.com](http://RCAAntennaHelp.com) para videos de instrucciones y prácticos.